

## NAME

rmdb - remove cell parts of an ICD database project

## SYNOPSIS

**rmdb** [-aifv] [-c *cellname*] [-p *project*] [layout] [circuit] [floorplan]

## OPTIONS

- a** Remove *all* cells of all views, if not further restricted by the **-c** option or one or more view specifications.
- i** Clean also *impcelllist* of views. Not allowed in combination with the **-c** option.
- f** Use *force* mode: no confirmations are asked.
- v** Use *verbose* mode.
- c** Remove *cell* with name <cellname> from database. Either the **-a** option (for all views) or one or more view specifications must be given.
- p** Use this *project* path for the database removals.

## DESCRIPTION

*Rmdb* can clean a complete ICD database or remove parts from it. It can remove all cells from one or more views together.

*Rmdb* can also remove individual cells from one or more views.

*Rmdb* asks for a confirmation, when option **-f** is not specified, before proceeding.

## NOTES

The current working directory must be the project directory.

You can use the environment variable CWD.

## EXAMPLES

```
% rmdb -aiv
```

The above example removes verbose *all* cells from *all* views and cleans also the "impcelllist" in the views.

```
% rmdb layout circuit
```

The above example removes *all* cells from the layout and circuit view.

```
% rmdb -c FlipFlop layout
```

The above example removes the FlipFlop cell from the layout view.

```
% rmdb -c FlipFlop -c nand2 -af
```

The above example removes the FlipFlop and nand2 cell from *all* views and does not ask for it.

## AUTHORS

S. de Graaf

## FILES

project/exp_dat	(removed, if layout view)
project/display.out	(removed, if layout view)
project/view/celllist	(cleaned)
project/view/impcelllist	(cleaned, option -i)
project/view/cell ...	(removed)

## DIAGNOSTICS

Generally self-explanatory. All messages are echoed on the *stderr* output.